

LIONHEART

- F O U N D R Y -



LF212 & LF412 USER MANUAL



CONTENTS

INTRODUCTION	2
LF212	2
LF412	3
REAR PANEL	4
CONNECTIONS	4
SPECIFICATIONS	5
LF212	5
INTERNAL CONNECTIONS	5
DIMENSIONS (in mm).....	6
LF412	7
INTERNAL CONNECTIONS	7
DIMENSIONS (in mm).....	8
SAFETY AND WARNINGS	9

INTRODUCTION

Everything you need. Nothing you don't.

Introducing the LF212 and LF412 matching Lionheart cabinets.

LF212

The open backed LF212, delivers uncompromising performance and robust durability in a 2x12 configuration. The LF212 produces a lovely warm low-end, a creamy rich vocal mid-range and a sparkling, beautifully detailed top-end and can be used whatever the style of music you choose to play.

ROAD READY

Engineered with twin 12" high-performance HH drivers, this 4-ohm cabinet offers exceptional sound clarity and an impressive power handling capacity of 480W peak output. Solid construction and protected by a hard-wearing vinyl finish with stainless steel metal corners.

GREAT GUITAR TONE

The secret of any great guitar tone is the driver. HH Acoustics painstakingly designed the LF212's H1260 driver, in the UK. Designed to deliver classic tones with remarkable precision. Its meticulous design ensures that every note you play is faithfully reproduced, from the cleanest of cleans to the grittiest, saturated overdrives.

Weighing just 14kg and featuring compact dimensions of 445 x 681 x 280mm, this cabinet provides guitar players with a versatile, high-quality solution that delivers pristine audio reproduction in any performance environment.

FEATURES

LFR-212

- High Sensitivity HH H1260 8Ω Woofers
- Side Mounted Heavy Duty Bar Handles
- Robust all wood construction
- hard wearing finish

LF412

Introducing the LF412, a stunning 4x12 matching Lionheart cabinet.

The Laney LF412 is an outstanding cabinet loaded with 4x12" HH H1260 premium drivers.

This closed-back speaker cabinet utilises time tested construction methods to deliver the bass, mid response and great sound you would expect from a Laney 4x12 cab.

The LF412 delivers an aggressive low-end, powerful low-mids plus attacking upper mid-range with a crystal-clear top- end.

Equipped with four 12" HH high-performance drivers, this 4-Ohm powerhouse delivers an extraordinary peak output of 960W, providing impact and clarity for demanding players.

ROAD READY

As with all Laney cabinets, the LF412 features robust construction with a hard-wearing vinyl finish and stainless-steel metal corners, the LF412 combines muscular durability with exceptional sound reproduction.

GREAT GUITAR TONE

The secret of any great guitar tone is the driver. HH Acoustics painstakingly designed the LF412's H1260 driver, in the UK. Designed to deliver classic tones with remarkable precision. Its meticulous design ensures that every note you play is faithfully reproduced, from the cleanest of cleans to the grittiest, saturated overdrives.

Measuring 696 x 681 x 350mm and weighing 24kg, this cabinet offers substantial audio presence without compromising portability, making it a perfect match for the SUPERTOP for live performances, studio recordings, and practice.

FEATURES

LFR-412



- High sensitivity HH H1260 16Ω Woofers
- Side Mounted Heavy Duty Bar Handles
- Robust all wood construction
- hard wearing finish

REAR PANEL


INPUT SOCKET - Use a good quality speaker cable to make the connection between the amplifier and LF212 or LF412 cabinet.

NOTE: the speaker's impedance should match or slightly exceed the amplifier's recommended output impedance range.

For example, if an amplifier output is rated for 4Ω speakers, using 4Ω or 8Ω higher speaker cabinet is recommended.



CONNECTIONS




SPECIFICATIONS




LF212

Model	LF212
Woofer Size	2x12" HH Designed High Performance driver - H1260
Nominal Cabinet Impedance	4 Ohm
Power Rating1	120W RMS, 240W Continuous, 480W Peak
Input Connector	6.3mm Jack Socket
Main Construction Material	Robust composite wood construction (15mm MDF)
Finish	Hard wearing Vinyl finish with stainless steel metal corners
Unit dimensions (HWD)	445 x 681 x 280mm, 17.5" x 26.8" x 11"
Unit weight	16.2Kg, 35.7 lbs
Carton dimensions (HWD)	520 x 750 x 345mm, 20.5" x 29.5" x 13.6", 0.135 M3
Packed weight	19.8Kg, 43.7 lbs
EAN Code	5060109459135


INTERNAL CONNECTIONS




DIMENSIONS (in mm)




TOP




FRONT



RIGHT



REAR




BASE




LF412

Model	LF412
Woofer Size	4x12" HH Designed High Performance driver - H1260
Nominal Cabinet Impedance	4 Ohm
Power Rating1	240W RMS, 480W Continuous, 960W Peak
Input Connector	6.3mm Jack Socket
Main Construction Material	Robust composite wood construction (15mm MDF)
Finish	Hard wearing Vinyl finish with stainless steel metal corners
Unit dimensions (HWD)	696 x 681 x 350mm, 27.4" x 26.8" x 13.8"
Unit weight	28.9Kg, 63.7 lbs
Carton dimensions (HWD)	770 x 750 x 410mm, 30.3" x 29.5" x 16.1", 0.237 M3
Packed weight	33.3Kg, 73.4 lbs
EAN Code	5060109459142


INTERNAL CONNECTIONS




DIMENSIONS (in mm)




TOP




FRONT



RIGHT



REAR









BASE

SAFETY AND WARNINGS

To take full advantage of your new product and enjoy long and trouble-free performance, please read this owner's manual carefully, and keep it in a safe place for future reference.

- 1) **Unpacking:** On unpacking your product, please check carefully for any signs of damage that may have occurred whilst in transit from the Laney factory to your dealer. In the unlikely event that there has been damage, please re-pack your unit in its original carton and consult your dealer. We strongly advise you to keep your original transit carton, since in the unlikely event that your unit should develop a fault, you will be able to return it to you dealer for rectification securely packed.
- 2) **Amplifier Connection:** To avoid damage, generally it is advisable to establish and follow a pattern for turning on and off your system. With all system parts connected, turn on source equipment, mixers, effects processors etc, BEFORE turning on your amplifier. Many products have large transient surges at turn on and off which can cause damage to your speakers. By turning on your amplifier LAST and making sure its level control is set to a minimum, any transients from other equipment should not reach your loudspeakers. Wait till all system parts have stabilised, usually a couple of seconds. Similarly, when turning off your system always turn down the level controls on your amplifier and then turn off its power before turning off other equipment.
- 3) **Cables:** Never use shielded or microphone cable for any speaker connections as this will not be substantial enough to handle the amplifier load and could cause damage to your complete system. Use good quality shielded cables everywhere else.
- 4) **Servicing:** The user should not attempt to service these products. Refer all servicing to qualified service personnel.
- 5) Heed all warnings.
- 6) Follow all instructions.
- 7) Do not use this apparatus near water.
- 8) Clean only with a dry cloth.
- 9) Do not block any of the ventilation openings. Install in accordance with manufacturer's instructions.
- 10) Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 11) An apparatus with Class I construction shall be connected to a mains socket outlet with a protective connection. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type of plug has two blades and a third grounding prong. The wide blade or third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- 12) Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point they exit from the apparatus.
- 13) Only use attachments/accessories provided by the manufacturer.
- 14) Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- 15) The mains plug or appliance coupler is used as the disconnect device and shall remain readily operable. The user should allow easy access to any mains plug, mains coupler and mains switch used in conjunction with this unit thus making it readily operable. Unplug this apparatus during lightning storms or when unused for long periods of time.
- 16) Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as when power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- 17) Never break off the ground pin. Connect only to a power supply of the type marked on the unit adjacent to the power supply cord.
- 18) If this product is to be mounted in an equipment rack, rear support should be provided.
- 19) **Note for UK only:** If the colours of the wires in the mains lead of this unit do not correspond with the terminals in your plug, proceed as follows:
 - o The wire that is coloured green and yellow must be connected to the terminal that is marked by the letter E, the earth symbol, coloured green or coloured green and yellow.
 - o The wire that is coloured blue must be connected to the terminal that is marked with the letter N or the colour black.
 - o The wire that is coloured brown must be connected to the terminal that is marked with the letter L or the colour red.
- 20) This electrical apparatus should not be exposed to dripping or splashing and care should be taken not to place objects containing liquids, such as vases, upon the apparatus.
- 21) Exposure to extremely high noise levels may cause a permanent hearing loss. Individuals vary considerably in susceptibility to noise-induced hearing loss, but nearly everyone will lose some hearing if exposed to sufficiently intense noise for a sufficient time. The U.S. Government's Occupational Safety and Health Administration (OSHA) has specified the following permissible noise level exposures: According to OSHA, any exposure more than the above permissible limits could result in some hearing loss. Earplugs or protectors to the ear canals or over the ears must be worn when operating this amplification system to prevent a permanent hearing loss, if exposure is more than the limits as set forth above. To ensure against potentially dangerous exposure to high sound pressure levels, it is recommended that all persons exposed to equipment capable of producing high sound pressure levels such as this amplification system be protected by hearing protectors while this unit is in operation.

Duration Per Day in Hours	Sound Level dBA, slow response
8	90
6	92
4	95
3	97
2	100
1 1/2	102
1	105
1/2	110
1/4 ou inférieur	115
- 22) If your appliance features a tilting mechanism or a kickback style cabinet, please use this design feature with caution. Due to the ease with which the amplifier can be moved between straight and tilted back positions, only use the amplifier on a level, stable surface. DO NOT operate the amplifier on a desk, table, shelf or otherwise unsuitable non-stable platform.
- 23) Symbols & nomenclature used on the product and in the product manuals, intended to alert the operator to areas where extra caution may be necessary, are as follows:

 CAUTION:	<p>Intended to alert the user to the presence of uninsulated 'Dangerous Voltage' within the products enclosure that may be sufficient to constitute a risk of electrical shock to persons.</p> <p>Ce symbole est utilisé pur indiquer a l'utilisateur de ce produit de tension non-isolée dangereuse pouvant être d'intensité suffisante pour constituer un risque de choc électrique.</p> <p>Este símbolo tiene el propósito de alertar al usuario de la presencia de '(voltaje) peligroso' que no tiene aislamiento dentro de la caja del producto que puede tener una magnitud suficiente como para constituir riesgo de corrientazo.</p> <p>Dieses Symbol soll den Anwender vor unisolierten gefährlichen Spannungen innerhalb des Gehäuses warnen, die von ausreichender Stärke sind, um einen elektrischen Schlag verursachen zu können.</p>
 WARNING:	<p>Intended to alert the user of the presence of important operating and maintenance (Servicing) instructions in the literature accompanying the product.</p> <p>Destiné à alerter l'utilisateur de la présence d'instructions importantes d'exploitation et de maintenance (entretien) dans la documentation accompagnant le produit.</p> <p>Este símbolo tiene el propósito de la alertar al usuario de las presencias de instrucciones importantes sobre la operación y mantenimiento en la literatura que viene con el producto.</p> <p>Dieses Symbol soll den Benutzer auf wichtige Instruktionen in der Bedienungsanleitung aufmerksam machen, die Handhabung und Wartung des Produkts betreffen.</p>
<p>CAUTION:</p> <p>ATTENTION :</p> <p>PRECAUCION:</p> <p>VORSICHT:</p>	<p>Risk of electrical shock - DO NOT OPEN. To reduce the risk of electrical shock, do not remove the cover. No user serviceable parts inside. Refer servicing to qualified personnel.</p> <p>Risques de choc électrique - NE PAS OUVIRIR. Afin de réduire le risque de choc électrique, ne pas enlever le couvercle. Il ne se trouve a l'intérieur aucune pièce pouvant être réparée par l'utilisateur. Confier l'entretien a un personnel qualifié.</p> <p>Riesgo de descarga eléctrica - NO ABRIR. Para reducir el riesgo de descarga eléctrica, no quite la cubierta. No hay piezas reparables por el usuario en el interior. Remita el servicio a personal calificado.</p> <p>Risiko - Elektrischer Schlag! Nicht offen! Um das Risiko eines elektrischen Schlages zu vermeiden, nicht die Abdeckung entfernen. Es befinden sich keine Teile darin, die vor Anwender repariert werden konnten. Reparaturen nur von qualifiziertem Fachpersonal durchführen lassen.</p>
<p>WARNING:</p> <p>ADVERTISSEMENT :</p> <p>ADVERTENCIA:</p> <p>ACHTUNG:</p>	<p>To prevent electrical shock or fire hazard, do not expose this appliance to rain or moisture. Before using this appliance, please read the operating instructions for further warnings.</p> <p>Afin de prévenir les risques de décharge électrique ou de feu, n'exposez pas cet appareil a la pluie ou a l'humidité. Avant d'utiliser cet appareil, lisez les avertissements supplantais situes dans le guide.</p> <p>Para evitar descargas eléctricas o peligro de incendio, no exponga este aparato a la lluvia ni a la humedad. Antes de usar este aparato, lea las instrucciones de funcionamiento para conocer más advertencias.</p> <p>Um einen elektrischen Schlag oder Feuergefahr zu vermeiden, sollte dieses Gerät nicht dem Regen oder Feuchtigkeit ausgesetzt werden. Vor Inbetriebnahme unbedingt die Bedienungsanleitung lesen.</p>
	<p>This device complies with Part 15 of the FCC rules Operation is subject to the following two conditions:</p> <ol style="list-style-type: none"> 1) This device may not cause harmful interference. 2) This device must accept any interference received, that may cause undesired operation. <p>Warning: Changes or modification to the equipment not approved by Laney can void the user's authority to use the equipment.</p> <p>Note: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures. Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.</p>
	<p>This product conforms to the requirements of the following European Regulations, Directives & Rules: CE Mark (93/68/EEC), Low Voltage (2014/35/EU), EMC (2014/30/EU), RoHS (2011/65/EU), ErP (2009/125/EU)</p> <p>SIMPLIFIED EU DECLARATION OF CONFORMITY</p> <p>Full text of the EU declaration of conformity is available at the following internet address:</p> <p>http://support.laney.co.uk/approvals</p>
	<p>The object of the declaration described above is in conformity with the relevant statutory requirement Electrical Equipment (Safety) Regulations 2016, Electromagnetic Compatibility Regulations 2016, The Restriction of the use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012, The Ecodesign for Energy-Related Products and Energy Information, (Amendment) (EU Exit) Regulations 2012</p>
	<p>In order to reduce environmental damage, at the end of its useful life, this product must not be disposed of along with normal household waste to landfill sites. It must be taken to an approved recycling centre according to the recommendations of the WEEE (Waste Electrical and Electronic Equipment) directive applicable in your country.</p>

LIONHEART

- F O U N D R Y -



LANEY ELECTRONICS LTD.
STEELPARK ROAD, COOMBSWOOD BUSINESS PARK WEST, HALESOWEN, B62 8HD. UK
FOR THE LATEST INFORMATION PLEASE VISIT WWW.LANEY.CO.UK

IN THE INTEREST OF CONTINUED DEVELOPMENT, LANEY RESERVES THE RIGHT TO AMEND PRODUCT SPECIFICATION WITHOUT PRIOR NOTIFICATION.